

inger Tips

Work Start

Go Ho

- Press the Home button anytime to return to the Home screen. Even while you're on a call, you can access your email, calendar or other applications, and even surf the web when you're connected via Wi-Fi.

The image shows two iPhone screens side-by-side. The left screen displays a text message from 'iPhone' with the text: 'iPhone to download answers to frequently earn even more Finger'. The right screen shows the home screen with icons for SMS, Calendar, Photos, and Camera. A status bar at the top of both screens indicates signal strength, battery level, and the time (9:42 AM). A vertical text overlay on the left side of the image reads 'Volume Up/Down'.

The image shows the home screen of an iPhone with several app icons visible. At the top, there are four icons: Clock, Calculator, Notes, and Settings. Below them is a purple iTunes icon. At the bottom, there are four more icons: Phone, Mail, Safari, and App Store.



To create a list of your favorite numbers, tap the Favorites button. Then tap the plus sign to add a new favorite from your Contacts. Tap Edit to remove or rearrange favorites. Tap the blue arrow next to a name to see their full contact information.

g.

mes in, push the Sleep/Wake button to silence the ring or push it immediately send the call to voicemail or silence all sounds with the



Rotate
art in C
track lis
outside
album a



ic in Cover Flow.

lick through your album
Tap any album to see its
any track to play it. Tap
list to flip back to the



Video cont

Tap your movie to bring up controls. Tap again to hide them. Double-tapping switches between widescreen and full screen.

Change your settings.
Tap the Settings button on the Home screen to turn on Airplane mode when flying, join a Wi-Fi network, change your screen brightness, wallpaper or ringtones, or select options for each application. You can check your usage time, and even add a passcode for added security.



Message previews.
Change how much of your message you see in the previews—from 0 to 5 lines—in Settings. To quickly delete an email or SMS message, flick from left to right across the message preview. Tap anywhere other than the red Delete button to cancel.



Accept or decline corrections.
While typing, tap the space bar to accept a suggested word or tap the suggested word to decline it. Start typing with just one finger. Once you trust iPhone's amazing auto-correction, try typing with both thumbs. Tap the ".?123" key to switch to number and symbol keyboards.




Magnify to edit text.
Touch and hold your finger on the text you want to edit to bring up the magnifying glass. Move your finger to position the insertion point, then edit using the keyboard.



See the web up close.
While browsing the web, double-tap any element—picture or text—to zoom in. Move your finger to position the insertion point, then edit using the keyboard.



Multiple web pages.
Type in an address, or tap one in Contacts or bookmarks it, to see its address and phone number (which you can tap to dial) or to ask for directions to or from that location. Tap the Directions button to enter starting and ending addresses. Tap the Start button for turn-by-turn directions.



Get directions.
Load your favorite photos onto iPhone with two fingers on the screen, pinch open to enlarge a photo and pinch closed to make it smaller. Double-tap to return to normal size. Rotate iPhone sideways to automatically display photos in landscape format. Rotate back for portrait.

